INSTALL INSTRUCTIONS

Exhaust Clamps

What's Included

Exhaust Clamp(s)
Bolts
Rubbers

Tools Needed

T-Handle
Flathead Screwdriver
Dish Soap

01 *Remove the pinch bolts, separate the rubber inserts from the clamp(s), and remove the stingers and silencers from the bike.*

02 *Take the billet part of the clamp with the bolt holes facing the outside of the bike and down, and slide over the header. Re-attach the stinger to the header, then slide the rubber insert over the header/stinger joint.*

03 *Use a small amount of dish soap and lubricate the inside of the rubber insert with your finger. Slide the rubber over the stinger. Make sure the rubber stays centered over the joint! Please note, the dish soap will dry within a few minutes of the engine running which will leave the clamp fit, firm and in place.*

04 *Spread the billet portion of the clamp with a wide flathead screwdriver or equivalent. Slide it over the rubber insert.*

CASCADE INNOVATIONS