INSTALL INSTRUCTIONS

Headlights

What's Included

2 LED Headlights
1 Set of Wire Connectors

Tools Needed

Blue Loctite
2mm T-Handle

01 Remove the three small set screws on each headlight and pull off the bulb cover. Check the bulb is fully connected inside the headlight assembly.

02 Coat the three small set screws you removed on each headlight with Blue Loctite and re-install the bulb covers.

03 Take either black wire from the headlight and wire it to the black wiring on your wiring harness.

04 Take the other black wire from the headlight and connect it to both the yellow and green wires on your wiring harness. This allows you to have your lights turn on in the low and high positions. The "off" will operate like before. (Technically there will no longer be a high and a low option, there will be two ons and an off.)

CASCADE INNOVATIONS