INSTALL INSTRUCTIONS

Knock Off Covers

What's Included

2 Knock Off Covers
2 O-Rings
2 Round Pins
2 Grommets

Tools Needed

Needle Nose Pliers
Small Round Punch

01 Remove the cotter pin from your spindel nut with needle nose pliers.

02 Open up your Knock Off Covers and proceed to roll the o-ring out of the o-ring groove. Once the o-ring is out of the way, you will find a round pin. Remove this round pin by pushing it out with a small round punch.

03 Slide the Knock Off Cover onto your spindle nut. Make sure to line up the hole on the Knock Off Cover with the hole on your spindle. Then, push in the round pin provided with the Knock Off Cover.

04 Roll the provided o-ring back over the round pin and into the o-ring groove.This will secure the round pin in place.

CASCADE INNOVATIONS